

How to Apply Static Cling Film to a Glass Window

Using static cling vinyl signs is a great way to display your products and services, at a relatively low cost to temporary signage. Here are some instructions to apply your new static cling window sign. Difficulty: Moderately Easy. KEEP the Static Cling Sign WET front and back to prevent clinging to its self VERY IMPORTANT.

Things you'll need:

- * 4-inch blue squeegee, (applicator) we supply for free.
- * 1 Spray bottles
- * 1/4 tsp. Mild dish detergent
- * 2 quarts Warm water
- * Lint-free paper towels
- * Level and tape measure

1. Pour 1 quart of warm water into one spray bottle. Pour 1/4 teaspoon dish detergent into the other spray bottle with 1 quart of warm water.
2. Wash your window with your paper towels and soap water. Be sure to get the window clean and streak-free.
3. Spray the window with your water bottle. And Static Window Sign. Keep it all wet front and back, VERY IMPORTANT to prevent clinging to its self.
4. Peel the film away from its backing. Start at one corner and gently pull the film free. KEEP IT WET.
5. Align the top edge of the film with the top of the window. Smooth the film onto the window from the top to the bottom with your hands. Lightly mist the film with water. Squeegee will slide nicely when static vinyl is kept wet.
6. Secure the top of the film to the window with your squeegee. Using the blue squeegee at a 45 degree angle (keep static vinyl wet) and work water out from center and out to all sides.
7. Working from the middle to each side and from top to bottom, slowly drag your squeegee across the film to secure it to the window. Be sure to hold the squeegee at an angle and work all the water and air from under the film, and KEEP IT WET.
8. Dry the film with lint-free paper towels and enjoy.